









ASSEMBLY GUIDE MEDIUM/LARGE END TABLE PET CRATE

Thank you for choosing a quality, handcrafted End Table Pet Crate from Dynamic Accents Ltd.

Your crate has been designed for quick and easy assembly requiring only the use of a manual or power Philips Head Screwdriver. Please ensure that all of the parts listed are included in your package.

For questions or comments, please contact Dynamic Accents, Ltd. (866)354-7334 www.dynamicaccents.com

Your Package Includes the following:

	Crate Side Panels	2
	Crate Back Panel	1
	Crate Front Panel w/Door	1
	Crate Bottom	1
	Crate Top	1
	1.25" Wood Screws	10



Use & Care:

- Always place product on a flat, even surface.
- Keep this product away from fire or extremely high temperatures.
- Do not use this product for anything other than it's intended purpose.
- The use of chemicals or harsh abrasives could damage the finish of this product.
- Do not sit or stand on this product as it could result in fall or injury.
- This product is not intended for pets that chew.

Step 1

Place the back panel on a flat, even, non-abrasive surface with the grooves facing up.

Place 1 side panel into position as shown in figure A by inserting the panel into the groove in the back panel.



Figure A



Figure B

Step 2

Place the bottom panel into position as shown in figures B & C, making sure that the panels are firmly butted together and the bottom panel is in the side and back grooves. Insert two wood screws into the back stabilizer rail and one through the side stabilizer rail until the screw heads are flush with the surface of the bars



Figure C

Step 3

Place the crate top (stabilizer rails facing up) next to the assembled panels as shown in Figure D and tip the assembled panels down onto the top. Ensure proper alignment by centering the assembled panels evenly left to right. Insert wood screws as shown in Figure E



Figure D



Figure E



Step 4

Place remaining side panel into position ensuring that it engages into the groove in the back panel and that the bottom panel is firmly seated into the groove on the side panel. You can now insert the wood screws through the stabilizer rail as shown in figure F

Step 5

Place the door panel into position, make sure to align the grooves in the door panel to the side and bottom panels. Insert the wood screws into the stabilizer bar only half way. DO NOT completely tighten down the screws until you have opened the door panel and reached inside the crate to insert the remaining screws as shown in figure H. Insert these screws completely. You can now tighten the previous screws the remainder of the way.



Figure F



Step 6

Your crate is now fully assembled. Rotate the entire crate on to it's glide feet and it is ready for use.



Figure G



Figure H